Android Using Menus

Victor Matos Cleveland State University

Notes are based on:

The Busy Coder's Guide to Android Development by Mark L. Murphy Copyright © 2008-2009 CommonsWare, LLC. ISBN: 978-0-9816780-0-9 & Android Developers http://developer.android.com/index.html





Menus usually increase the functionality of an app by providing additional operations on a small overlapping panel.

Android provides two types of menu known as: options menu and context menu.


- 1. The *options menu* is triggered by pressing the hardware Menu button on the device, while
- 2. the *context menu* is raised by a *tap-and-hold* on the widget associated to the menu.



Example: Using an option menu



A max of six entries per menu. Excess will be displayed as part of the **More** option






Example:

Using an option menu

Five available
Options in —
this context






Example:

Dealing with SMS (text-messages) by using the built-in Messaging app's context menu

₩ 📶 🕰 4:08 PM **S** Google Search Available options 3:45 PM Beatriz Matos <216-555-1234> Beatriz Matos: can you read me now? Sent: Jul 20 Beatriz Matos: Msg sent from Eclipse's Emulator Control Sent: Jul 20 Beatriz Matos: Get some milk and bread in your way home. Sent: 3:44PM Type to compose Send



Tap-&-Hold



Observation:


Option and **Context** Menus may include:

- 1. Text
- 2. Icons
- 3. Radio Buttons
- 4. Check Boxes
- 5. Sub-menus
- 6. Short-cut keys



Example 1: Using an Option Menu

In this application the Option menu offers a way of changing the text size (on both EditText boxes)





Click on **Menu** button to see size options


After choosing option: **50 points**




Example 1: Using an Option Menu

Up to six options will Be displayed on the Option menu.

If there are more than six options pushing the **More** button will show the rest



Click the **More** button to see additional options




Additional choices of the Option menu




Example 1: Using a Context Menu

Each view could have an associated Context Menu



Long-press a textbox to invoke its Context Menu





Example 1: Using Option and Context Menu

```
<?xml version="1.0" encoding="utf-8"?>
<LinearLayout xmlns:android="http://schemas.android.com/apk/res/android"</pre>
    android:orientation="vertical"
    android:layout width="fill parent"
                                                                             🔛 📶 🔼 2:48 PM
    android:layout height="fill parent" >
                                                                    Hello world
<EditText
     android:id="@+id/etMessage1"
                                                                    Hola mundo
     android:text="Hello world"
                                                                        Press the MENU key, or
     android: layout width="fill parent"
     android: layout height="wrap content"
     android:layout margin = "5dp" />
<EditText
     android:id="@+id/etMessage2"
     android:text="Hola mundo"
     android:layout width="fill parent"
     android: layout height="wrap content"
     android:layout margin = "5dp" />
<TextView
     android:text="Press the MENU key, or \nLong-press text-boxes"
     android:layout width="wrap content"
     android:layout height="wrap content"
     android:layout gravity="center" />
</LinearLayout>
```



Example 1: Using Option and Context Menu

```
package cis493.matos.menu;
// using Menus (Option & Context)
import android.app.Activity; ...
public class MenulAct1 extends Activity {
    EditText etMessage1;
    EditText etMessage2;
    Integer[] arrayPointSize = {10, 20, 30, 40, 50};
    @Override
    public void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        setContentView(R.layout.main);
        etMessage1 = (EditText)findViewById(R.id.etMessage1);
        etMessage2 = (EditText)findViewById(R.id.etMessage2);
        // you may register an individual context menu for each view
        registerForContextMenu(etMessage1);
        registerForContextMenu(etMessage2);
    } //onCreate
```



Example 1: Using Option and Context Menu

```
// set the option menu for the current activity
@Override
public boolean onCreateOptionsMenu(Menu menu) {
    // only one Option menu per activity
    populateMyFirstMenu(menu);
    return super.onCreateOptionsMenu(menu);
// detect what view is calling and create its context menu
@Override
public void onCreateContextMenu(ContextMenu menu, View v,
                                ContextMenuInfo menuInfo) {
    super.onCreateContextMenu(menu, v, menuInfo);
    // decide what context menu needs to be made
    if (v.getId() == etMessage1.getId())
        // create a menu for etMessage1 box
        populateMyFirstMenu(menu);
    if (v.getId() == etMessage2.getId()){
        // create a menu for etMessage2 box
        populateMySecondMenu(menu);
  //onCreateContextMenu
```



Example 1: Using Option and Context Menu

```
private void populateMyFirstMenu(Menu menu) {
    int groupId = 0; int order= 0;
    //arguments: groupId, optionId, order, title
    menu.add(groupId, 1, 1, "10 points");
    menu.add(groupId, 2, 2, "20 points");
    menu.add(groupId, 3, 3, "30 points");
    menu.add(groupId, 4, 4, "40 points");
    menu.add(groupId, 5, 5, "50 points");
    menu.add(groupId, 6, 8, "Red text");
    menu.add(groupId, 7, 7, "Green Text");
    menu.add(groupId, 8, 6, "Blue text");
} //populateMyMenu
private void populateMySecondMenu(Menu menu) {
    int groupId = 0; int order= 0;
    //arguments: groupId, optionId, order, title
    menu.add(groupId, 9, 1, "Bold");
    menu.add(groupId, 10, 2, "Italic");
    menu.add(groupId, 11, 3, "Normal");
}//populateMySecondMenu
```



Example 1: Using Option and Context Menu

The app shows two text boxes. Menus are used to change text's size, color, and style.

```
// called whenever an item in your context menu is selected
@Override
public boolean onContextItemSelected(MenuItem item) {
    return (applyMenuOption (item) | |
           super.onContextItemSelected(item) );
// called whenever an item in your options menu is selected
@Override
public boolean onOptionsItemSelected(MenuItem item) {
    return(applyMenuOption(item) ||
           super.onOptionsItemSelected(item) );
```

Note: boolean event observers of the type onEvent(...) by convention return **true** to indicate the triggered event has been consumed by the method, when **false** is returned the event is still alive and could be consumed by others.



Example 1: Using Option and Context Menu

```
// apply the action associated to selected item
private boolean applyMenuOption(MenuItem item) {
     int menuItemId = item.getItemId(); // 1, 2, 3, ...11
     String strMsq2 = etMessage2.getText().toString();
     if (menuItemId <= 5) {</pre>
          // first five option are for setting text size
          int newPointSize = arrayPointSize[menuItemId - 1];
          etMessage1.setTextSize(newPointSize);
          etMessage2.setTextSize(newPointSize);
     else {
          // either change color on box text1 or style on text2
          if (menuItemId == 6)
               etMessage1.setTextColor(color.background dark | Color.RED);
               etMessage1.setTextColor(0xffff0000); // red
          else if (menuItemId == 7)
               etMessage1.setTextColor(0xff00ff00); // green
          else if (menuItemId == 8)
               etMessage1.setTextColor(0xff0000ff); // blue
          else if (menuItemId == 9)
               etMessage2.setText(beautify(strMsq2, "BOLD")); //bold
          else if (menuItemId == 10)
               etMessage2.setText(beautify(strMsg2, "ITALIC")); //italic
          else if (menuItemId == 11)
               etMessage2.setText(beautify(strMsg2, "NORMAL")); //normal
return false;
} //applyMenuOption
```



Example 1: Using Option and Context Menu

```
// changing text style using HTML formatting
   // Spanned is text to which you could add formatting features
   private Spanned beautify (String originalText, String selectedStyle) {
        Spanned answer = null;
        if (selectedStyle.equals("BOLD"))
            answer = Html.fromHtml("<b>" + originalText +"</b");
        else if (selectedStyle.equals("ITALIC"))
            answer = Html.fromHtml("\langle i \rangle" + originalText +"\langle i \rangle");
       else if (selectedStyle.equals("NORMAL"))
            answer = Html.fromHtml("<normal>" + originalText +"</normal");</pre>
        return answer;
   } //beautify
//MenulActl
```



Comments on Creating an Option & Context Menu

Step1.

Indicate which widget(s) on your activity have context menus. To do this, call registerForContextMenu(theWidget)

supplying the View that is the widget needing a context menu.

Step2.

Implement **onCreateContextMenu(...)**, populate your menu adding text, icons, etc. to the different options. Use input **menu** parameter to determine which menu to build (assuming your activity has more than one).

The **onCreateContextMenu()** method gets the **ContextMenu** itself, the **View** the context menu is associated with, and a **ContextMenu.ContextMenuInfo**, which tells you which item in the list the user did the tap-and-hold over, in case you want to customize the context menu based on that information



Comments on Creating an Option & Context Menu

- onCreateContextMenu() is called each time the context menu is requested.
- Unlike the options menu (which is only built once per activity), context menus are discarded once they are used or dismissed.
- To find out when a context menu choice was chosen, implement onContextItemSelected() on the activity.



Comments on Creating an Option & Context Menu

In Example1 the event observers:

```
onOptionsItemSelected() (for options menu selections) and
onContextItemSelected() (for context menu selections)
```

delegate on the *applyMenuChoice*(...) method the performing of the actions associated to the choices made by the user.


```
@Override
public boolean onOptionsItemSelected(MenuItem item) {
    return (applyMenuChoice(item));
}


@Override
public boolean onContextItemSelected(MenuItem item) {
    return (applyMenuChoice(item));
}
```



Example 2: Enhancing Option/Context Menu

This extension of the previous example adds icons and links to the Option Menu entries, as well as a sub-menu list tied to one the option menu buttons.







Click on **SubMenu** to see additional options



Example 2: Enhancing Option/Context Menu

This extension of the previous example adds icons and links to the Option Menu entries, as well as a sub-menu list tied to one the option menu buttons.







Example 2: Enhancing Option/Context Menu

```
private void populateMyFirstMenu(Menu menu) {
     int groupId = 0;
     //arguments: groupId, optionId, order, title
     MenuItem item1 = menu.add(groupId, 1, 1, "10 points");
     MenuItem item2 = menu.add(groupId, 2, 2, "20 points");
     MenuItem item3 = menu.add(groupId, 3, 3, "30 points");
     MenuItem item4 = menu.add(groupId, 4, 4, "40 points");
     //MenuItem item5 = menu.add(groupId, 5, 5, "50 points");
     MenuItem item6 = menu.add(groupId, 6, 8, "Red text");
     MenuItem item7 = menu.add(groupId, 7, 7, "Green Text");
     MenuItem item8 = menu.add(groupId, 8, 6, "Blue text");
     //set icons
     item1.setIcon(R.drawable.uno);
     item2.setIcon(R.drawable.dos);
     item3.setIcon(R.drawable.tres);
     item4.setIcon(R.drawable.cuatro);
     // shortcuts using device's keyboard-keypad
     // on a G1 open slide open the keyboard and
     // type letter u (same as pressing menu UNO)
     item1.setShortcut('1', '1');
     item2.setShortcut('2', '2');
     item3.setShortcut('3', '3');
     item4.setShortcut('4', '4');
```

Replace the method **populateMyFirstMenu** with the following code

Remove this line from previous version

Figures used in this example were taken from: C:\android-sdk-windows\platforms\android-4\data\res\drawable













//populateMyFirstMenu

Using Menus

Extending Example 1.

Continuation... Replace the method populateMyFirstMenu with the following code

Sub Menu 5-2

Sub Menu 5-3

Example 2: Enhancing Option/Context Menu

```
// adding a sub-menu as fifth entry of this menu
// .addSubMenu(int groupId, int itemId, int order, CharSequence title)
                                                                                 10 points
                                                                                          20 points
int smGroupId = 0; // don't care, same as Menu.NONE
int smItemId = 5; // fifth element
                                                                                 30 points
                                                                                           40 points
                                                                                           int smOrder = 5;  // don't care, same as Menu.NONE
SubMenu mySubMenu5 = menu.addSubMenu(smGroupId, smItemId, smOrder, "Sub-Menu-CINCO");
mySubMenu5.setHeaderIcon(R.drawable.btn rating star on pressed);
mySubMenu5.setIcon(R.drawable.cinco);
                                                                                   🔛 📶 🛂 12:24 PM
// .add(int groupId, int itemId, int order, CharSequence title)
                                                                        You have selected:
MenuItem sub51 = mySubMenu5.add(smGroupId,5,1,"Sub Menu 5-1");
                                                                        Sub-Menu-CINCO Id: 5
MenuItem sub52 = mySubMenu5.add(smGroupId,5,2,"Sub Menu 5-2");
MenuItem sub53 = mySubMenu5.add(smGroupId,5,3,"Sub Menu 5-3");
                                                                            Sub-Menu-CINCO
                                                                         Sub Menu 5-1
```

23



Example 2: Enhancing Option/Context Menu

Continuation...
Replace the method
applyMenuOption
with the following code

```
private boolean applyMenuOption(MenuItem item) {
    int menuItemId = item.getItemId(); //1, 2, 3, ...11
    String strMsg2 = etMessage2.getText().toString();
    if (menuItemId < 5) {</pre>
         // first four options are for setting text size
                                                                      Same as before
         int newPointSize = arrayPointSize[menuItemId - 1];
         etMessage1.setTextSize(newPointSize);
         etMessage2.setTextSize(newPointSize);
                                                                      Take care of sub-
    else if (menuItemId == 5) {
                                                                      menu here
         // the sub-menu (attached to 5th item) is processed here
         etMessage1.setText (
                      "You have selected: \n" +item.getTitle()
                    + "\nId: " + menuItemId
                    + " order: " + item.getOrder() );
    // either change color on text1 or style on text2
    else if (menuItemId == 6)
         etMessage1.setTextColor(0xffff0000); // red
```



Example 2: Enhancing Option/Context Menu

Continuation...
Replace the method
applyMenuOption
with the following code

```
else if (menuItemId == 7)
    etMessage1.setTextColor(0xff00ff00); // green
else if (menuItemId == 8)
    etMessage1.setTextColor(0xff0000ff); // blue
else if (menuItemId == 9)
    etMessage2.setText(beautify(strMsg2, "BOLD")); //bold
else if (menuItemId == 10)
    etMessage2.setText(beautify(strMsg2, "ITALIC")); //italic
else if (menuItemId == 11)
    etMessage2.setText(beautify(strMsg2, "NORMAL")); //normal
return false;
//applyMenuOption
```



Questions?